

# USING YOUR XP4500iH-PK PARALLEL KIT

## Parallel Usage



### 1. Connect Ground

Connect one side of the **GREEN** cable to the ground bolt found in the bottom center of the panel of Generator 1.



### 2. Connect Positive

Connect the corresponding **RED** cable to the **RED** parallel port on the front panel of Generator 1.



### 3. Connect Negative

Connect the corresponding **BLACK** cable to the **BLACK** parallel port on the front panel of Generator 1.



### 4. Repeat on Generator 2

Repeat steps 1 - 3 on Generator 2. Combined power will be available from either receptacle on the Parallel Kit.



**CAUTION:** Do not connect **RED** (positive) cable to the **BLACK** (negative) receptacle. Damage to the generator(s) may occur.