


## NEW STYLE TRANSFER ASSEMBLY (Old Style Switch Other Side)


Allows multiple RXT transfer switches to be installed in series WITHOUT the installation of an RDT transfer switch

**ATTENTION: JUMPER MUST BE INSTALLED OR THE PRODUCT WARRANTY WILL BE VOIDED**



Remove connector P-13 and remove RXT control board. Insert connector P-13 plug into KTSE-1 Expander Module and attach to side panel of enclosure. Note: The RXT control board is not required to operate the transfer switch in the SLAVE mode and can be returned to inventory.

### SLAVE RXT



Connect coil B to the ONLY open terminal on the bottom micro-switch

### MASTER RXT




**Important: Risk of electrical shock.**  
This device should only be installed by qualified personnel.

**OLD STYLE TRANSFER ASSEMBLY**

Allows multiple RXT transfer switches to be installed in series WITHOUT the installation of an RDT transfer switch

**ATTENTION: JUMPER MUST BE INSTALLED OR THE PRODUCT WARRANTY WILL BE VOIDED**



To additional slave transfer switches when used

Remove connector P-13 and remove RXT control board. Insert connector P-13 plug into KTSE-1 Expander Module and attach to side panel of enclosure.

Note: The RXT control board is not required to operate the transfer switch in the SLAVE mode and can be returned to inventory.

Install Micro-Switch provided and connect to Common & Normally Open terminals

**SLAVE RXT**

**MASTER RXT**



**Important: Risk of electrical shock.**  
This device should only be installed by qualified personnel.